CITRUS BAR

instruction manual

DASH™

bydash.com

CITRUS BAR

Safety Guidelines 4-5

What's Inside 6-7

Setting Up Your Juicer 8-9

Using Your Juicer 10-11

Cleaning Your Juicer 12-13

Customer Support 14

Warranty 15

IMPORTANT SAFETY GUIDELINES

When using electrical appliances, basic safety precautions should be observed, especially the following:

- Read these instructions carefully.
- Remove all packaging and labels from appliance prior to use.
- Any maintenance other than cleaning please contact StoreBound toll free at 1-800-898-6970 from 7AM -7PM PST Monday through Friday or by email at info@storebound.com
- To protect against risk of electrical shock, do not put cord, plugs, or appliance in or near water or other liquid.
- Disconnect from main power outlet when not in use.
- Do not leave the appliance unattended when in use.
- Always use the appliance on a dry, level surface.
- Only use citrus fruits with this product, other food may damage the appliance.
- Unit will not operate unless pressure is applied to both Reamers only.
- Do not use the appliance if the rotating Drive Shafts are damaged.
- Unplug from outlet when not in use, during assembly, during disassembly, and before cleaning.
- When cleaning, do not submerge the motor base in any liquid. Instead, use a soft damp cloth to wipe down.
- Use only attachments recommended or sold by the manufacturer - using other attachments may result in fire, electric shock, or injury.
- Do not let the cord hang over the edge of a table or counter, become knotted or touch hot surfaces.
- For household use only.
- Make sure to turn Power Switch to "**O**" (off) position after each use of your juicer.
- Make sure the motor stops completely before disassembling.
- Do not use the appliance if any parts are damaged.
- Do not operate this appliance with a damaged cord, damaged plug, after the appliance malfunctions, is dropped, or is damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety,
- Keep appliance away from children when in use.
- WARNING: Do not use the appliance near water, other liquids, with wet hands or while standing on a wet surface.

- Avoid contact with moving parts.
- Do not use this appliance outdoors.
- Appliances are not intended to be operated by means of an external timer or separate remote-control system
- Switch off the appliance by disconnecting from main supply when the appliance is not intend to use.
- Do not place on or near a hot gas, hot electric burner, or in a heated oven.
- Appliance is not intended for use by children.

Lid 1
Citrus Blade 2
Front Disassembly Lever 3
Motor Base 4
5 On/Off Power Switch

6 Locking Rods

Reamers 7

8 Slicing Compartment

Juicing Chamber 9

10 Drive Shafts

Juice Container 11

12 Drip Tray

ASSEMBLY

Do not use the appliance near water, other liquids, with wet hands or while standing on a wet surface.

1. Set the Motor Base on a clean, stable and dry surface.

2. Place the Juicing Chamber onto the Motor Base by sliding the Juicing Chamber into the slots located near the back of the Motor Base. Then, gently press the Juicing Chamber down until it clips into the Motor Base.

3. Place the Reamers onto the Drive Shafts.

4. Slide the Locking Rods into the slots in the back of the Juicing Chamber.

5. Insert the Drip Tray into the guide rails in the Motor Base. Slide the Drip Tray into position until it locks.

6. Slide the Juice Container on top of the Drip Tray.

7. Unwind the power cord to the length you require and make sure the cord is intact before plugging in your appliance.

   Your Dash Citrus Bar is now ready for use!

USING YOUR CITRUS BAR

Make sure to clean the juicer thoroughly first before using. Do not fill the Juice Container above the max fill line.

1. Plug the appliance cord into a power outlet.
2. Flip the Power Switch on the side of the Motor Base to the "**I**" position to turn the Juicer on.
3. Place the fruit into the Slicing Compartment.
4. Lower the Lid to cut the fruit into halves.
5. Place each orange half onto the Reamers one at a time.
6. Lower lid using both hands on either side, apply firm pressure. This will start the juicing operation and juice will flow into the Juice Container.

Note: The appliance will not operate until pressure is applied to both Reamers simultaneously.

7. When the fruit halves are fully juiced, discard peels and repeat steps 5 & 6 until the Juice Container is full.
8. Slide the Juice Container out and begin to serve. The Drip Tray will catch any remaining juice from the Juicing Chamber.

TIPS & TRICKS

If the Juicer stops during juicing, the Reamers may be jammed by excess pulp. Rinse the Juicing Chamber and remove the pulp stuck underneath the Reamers.

health fact!

Many people think that calcium is only present in dairy. However, calcium is actually present in high amounts in citrus fruits as well.

MAINTENANCE

After each use, the Citrus Bar should be cleaned properly. Keep the Citrus Bar in a dry and well ventilated area. If not used for more than 3 days, make sure to wash the parts before next use.

DISASSEMBLE

1. Switch the appliance off and make sure to disconnect from the power outlet before changing any accessories.
2. Slide out the Juice Container.
3. Open the Lid fully with both hands placed on each side. Slide the Locking Rods out of the slots on the back of the Juicing Chamber.
4. Hold the Motor Base with one hand and with the other, gently push the Front Disassembly Lever upwards until it pops open. Slide the Juicing Chamber off of the Motor Base. To prevent juice from dripping, remove the Reamers and Juicing Chamber together.
5. The Reamers may also be removed separately from the Juicing Chamber by simply lifting them off of the Drive Shafts.
6. Slide the Drip Tray out of the Motor Base.

CLEAN

- **IMPORTANT: Do not immerse the Motor Base in water or any liquid. Instead, use a damp cloth to wipe the Motor Base.**
- Make sure to always turn off and unplug the appliance if left unattended and before assembling, disassembling or cleaning.
- Use warm, soapy water to wash all non-electrical parts.
- The Juicing Chamber may discolor over time due to contact with citrus.
- Never use any abrasive cleaning agents for cleaning as they may cause damage to the Citrus Bar.

health fact!

Did you know most juices you get at the grocery store contain ingredients you can't even pronounce? Juice at home, and get all the nutrients without the junk.

CUSTOMER SUPPORT

If your device fails to function as required, please check the troubleshooting checklist on bydash.com. There may only be a minor problem that you can solve yourself.

For product support, warranty and maintenance related questions (other than cleaning) please contact StoreBound directly at: 1-800-898-6970 from 7AM to 7PM PST, Monday - Friday, or by email at info@storebound.com.

REPAIRS

DANGER! Risk of electric shock! The Dash Citrus Bar is an electrical appliance. Do not attempt to repair the appliance yourself under any circumstances.

Contact Customer Care at 1-800-898-6970 regarding repairs to the device.

TECHNICAL SPECIFICATIONS

Model Number	DCJ001SIL	**Power Rating**	90 Watts
Voltage	120V ~ 60Hz		

WARRANTY

STOREBOUND, LLC – 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound will repair or replace the defective part. To process a warranty claim, contact Customer Care at 1-800-898-6970 for further assistance and instruction. A customer care agent will conduct troubleshooting in an attempt to fix any minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO Box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send All Inquires To: info@storebound.com

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER, STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

STOREBOUND™

STOREBOUND MAKES PRODUCTS
THAT MAKE PEOPLE'S LIVES HAPPIER,
HEALTHIER, AND EASIER.

IF YOU'VE GOT A GREAT IDEA FOR A
PRODUCT, WE WANT TO HEAR ABOUT IT.
GO TO OUR WEBSITE AT STOREBOUND.COM

visit **bydash.com**

© 2013 by StoreBound
StoreBound LLC, New York, 10038